

V-70 / S-70 / C-70 (Black box)

Located on the left side (drivers side) of the dash attached to the steering column.



Remove the 3 screws holding the kick panel to the dash. Pull the panel down and out.

The module is located above the kick panel. It's attached to steering column under the dash.



Slide immobilizer box up (push upwards.) The box will unsnap and the bottom will lift out from the holder.

Module in its mount.

This is the empty immobilizer module bracket (attached to the column).

